



Battery Precautions

1. Do not use rechargeable batteries.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Batteries are to be inserted with the correct polarity.
4. Keep batteries away from children.
5. Exhausted batteries according to local legal requirements. Do not dispose of them by throwing away with normal household rubbish.
6. Avoid short circuiting the contacts in the battery compartment and battery terminals.
7. Remove batteries from the unit if it will be not used for long period of time.

Battery Installation

- Insert 1 X AA (1.5V) battery observing the correct polarity, as shown on the diagram.
- Replace battery cover.

Radio Controlled Operation MSF Version (UK Only)

The Braun Quadrondo is controlled and set automatically by MSF radio signal. It is a dedicated time broadcast that provides an accurate and reliable source of UK civil time, based on the NPL time scale UTC(NPL).

Radio Controlled Clock Operation

Once the battery is inserted within three minutes the hour and minute hands will move to one of the three stand by positions at 4:00, 8:00 or 12:00 o'clock depending on which is the closest to the actual hands position.

After the hands have reached this position the clock will search for the Radio Controlled signal. If the signal is strong in your area, within 10 minutes the clock will be set to the correct time. The hour and minute hands will move to the actual time position.

A time check is carried out each even hour and additionally it broadcast a Radio Controlled Signal at 3 o'clock am and time is compared with the clock, and if required it will be corrected.

Please note that the hands will not move until successful signal is received.

A time check is carried out each even hour and additionally it broadcasts a Radio Controlled Signal at 3 o'clock am and time is compared with the clock, and if required it will be corrected.

Manual Time Setting MSF Version (UK Only)

The clock has an option to set manually to your desired time. Follow below procedures to set the clock on a manual time:

- Remove battery from the compartment
- Replace battery after approx 1 minute, the hands will move to one of the stand by position at 4, 8 or 12 o'clock position.
- Press and hold the TIME SET button to set the desired time.

Important:

- During manual setting the TIME SET button can only be pressed once. The button cannot be pressed again as this will cause clock to move hands to stand by position to receive Radio Control signal. To set the time manually above procedures will have to be repeated.
- When the clock is set to manual time the Radio Control function is disabled. To reactivate the Radio Control signal remove and replace the battery after 1 minute and clock will set itself to one of the stand by position at 4, 8 or 12 o'clock position. Please refer to "Radio Controlled Clock Operation" section.

Alarm Setting

To set alarm follow below procedures:

- Turn the button anti-clockwise to set the alarm time and push the button back into the position.
- Press the ALARM TAB located on the top to activate the alarm, green bar will be shown at the front above.

Alarm/Snooze Function

When the alarm time is reached a buzzer will sound together with backlight (5 seconds only). The alarm will sound for 2 minutes if no buttons are pressed. Press the alarm tab on the front to stop the alarm. The SNOOZE/LIGHT button is located at the bottom of the clock housing and can be activated when pressing on the clock body downwards. To activate the snooze function again press the clock body downwards and the alarm sound will stop and resumes after approx 4 minutes interval.

Reset Function

The clock has a hands setting help function. By pressing the reset button at any time, the hands will automatically move to the 12 o'clock position. The motor will then stop and at this point the battery must be removed. Please then wait at least 1 minute before reinserting the battery to start reception.

Backlight Function

During normal time, press clock body downwards to activate backlight.

Note: While the clock is receiving Radio Control Signal backlight will not function. Pressing the backlight button during this time can cause interference with Radio Control reception

GUARANTEE

2 year guarantee against material and workmanship defects (except battery). The guarantee is valid in those countries where the alarm clock is officially being sold.

Broken or cracked lens screens are not covered under the Guarantee.



Braun info line

BRAUN HELPLINE

Should you have a problem with your product, please check your local service centre at:

www.braun-clocks.com
www.braun-watches.com

or contact +44 208 208 1833



WARNING! This product is covered by the Waste Electrical and Electronic Equipment (WEEE) directive. It should not be discarded with normal household waste but taken to your local collection centre for recycling.



This product conforms to the EMC requirements as per council directive 89/36/EEC.

Braun is a registered trademark of Braun GmbH, Kronberg, Germany used under license by Zeon Ltd

BRAUN

BNC007 MSF

Radio Controlled

User Instructions
Guarantee